

The Americas

PRODUCT CATALOG

2016

Version 1.0









The Americas

PRODUCT CATALOG

2016

Version 1.0

AIR PURIFYING RESPIRATORS (APR)	
PC50	4
C50	5
FM50	6
FM53	7
POWERED AIR DEVICES	
Avon EZAir	8
STPAPR	9
C420	10
SELF CONTAINED BREATHING APPARATUS (Se	CBA)
ST Configuration	11
ST53	12
ST53SD	13
CBRN ESCAPE	
NH15 CBRN Escape Hood	14
NH15 Training Hood 14	
NH15 H ₂ S Escape Hood 14	
CRS15 15	

ACCESSORIES	
Filtration	16
Communication Accessories	20
Vision Accessories	23
Storage & Carriers	25
Hydration Accessories	26
Maintenance Tools	27
Special Tools	27
SPARE PARTS	
APR Spare Parts	28
Powered Air Spare Parts	31
User Manuals	33
20% restocking charge for returns	
Minimum order value of \$250 per transaction	

Disclaimer: As Avon continues to make improvements to our products, some part numbers and descriptions are subject to change

Avon products and associated technical information are controlled under U.S. export laws and regulations and are subject to the International Traffic in Arms Regulations (ITAR) under the U.S. Department of State (DOS), Directorate of Defense Trade Controls (22 CFR 120-128 and 130) and the Export Administration Regulations (EAR) under the U.S. Department of Commerce (DOC), Bureau of Industry and Security (22 CFR 730-774). Prior authorization from the U.S. Government may be required for any export, re-export, transfer, or re-transfer.

PC50

The Avon PC50 Air Purifying Respirator (APR) is based off the widely deployed C50™ and is designed and approved for use as a Non-CBRN respiratory device, providing protection in dangerous and contaminated environments, against certain solid and liquid respirable particles, gases, vapors and the splash of liquid chemicals.

The PC50 was specifically developed for the targeted user groups that demand a robust, field proven, competitively priced military pedigree product that meets their operational needs.

The Avon PC50 is available in three sizes, with either left or right hand 40mm canister mounts that accept traditional or conformal Canisters. The standard communication port allows the ability to connect with other radios. The PC50 head harness provides a comfortable and secure fit and is designed for rapid donning and doffing. The Avon PC50 may be fitted with a vision correction system and a variety of outserts for specific operational situations. Designed for the lowest cost of ownership and maximum reliability.

The PC50 is NIOSH approved for use with the Riot Control CTCF50 Canister providing protection against CS-CN agents in both vapor and aerosol form and particulate matter.





PC50 APR		
INCLUDES		
p/n	Description	
	PC50 APR Assembly	
70501-53	Faceform	
70501-612	PC50 User Manual	
p/n	Description	

70301 012	. coo osci mariaar
p/n	Description
70501-632	PC50 APR Assembly LGE
70501-633	PC50 APR Assembly MED
70501-634	PC50 APR Assembly SML

PC50 ENFORCER KIT		
	INCLUDES	
p/n	Description	
	PC50 APR	
70501-156	Clear Outsert Assembly	
71510-157	Sunlight Outsert Assembly	
72606-2	CTCF50 Riot Canister (Sold in packs of 4 -72606-3)	
72601-53	Faceform	
p/n	Description	
70501-628-1	PC50 Enforcer Kit LGE	
70501-628-2	PC50 Enforcer Kit MED	
70501-628-3	PC50 Enforcer Kit SML	



INCLUDES		
p/n	Description	
	C50 CBRN Twin Port APR	
70501-156	Clear Outsert Assembly	
70501-157	Sunlight Outsert Assembly	
72602-2	CBRNCF50	
72606-2	CTCF50 Riot Canister (Sold in packs of 4 -72606-:	
72601-32	Universal Carrier	
70501-227	Storage Bag	
72601-53	Faceform	
p/n	Description	
70501-555	C50 First Responder Kit LGE	
70501-556	C50 First Responder Kit MED	

70501-557

C50 FIRST RESPONDER KIT

INCLLIDES

C50 First Responder Kit SML

The Avon C50 APR is the NIOSH certified variant of the DOD JSGPM/M50 APR.

Available in 3 sizes, the C50 features a panoramic flexible visor, Electronic Communication Port (ECP) and high-flow failsafe hydration device.

The C50 APR is NIOSH certified in the following configurations:

- C50 is NIOSH CBRN Cap 1 approved with the CBRN Canister
- C50 is NIOSH 42 CFR 84 riot control CS-CN-P100 approved with the CTCF50 Canister
- NFPA 1994 Class 3 Approved with several suit ensembles
- Optional Voice Projection Unit (VPU) with internal microphone
- Full range of Outserts available
- Vision Correction System allows prescription lenses to be mounted inside the mask

The C50 meets the latest NATO military standards.

The Canister side can be changed left or right using Canister Mount Plug Tool (70501-161)

The C50 is supplied with a black storage bag and end user instructions.

The C50 First Responder kit has been specifically developed with the help of industry experts to provide a total CBRN respiratory solution for the end user. The kit provides a reduced acquisition cost when compared to purchasing the included items separately.



70501-84 User Instructions		User Instructions
	p/n	Description
	70501-187	C50 APR Assembly LGE
	70501-188	C50 APR Assembly MED
	70501-189	C50 APR Assembly SML

FM50

The FM50 APR is a commercial derivative of the Avon JSGPM/M50 military APR that utilizes the M50's unique conformal Canister configuration for military and specialist applications.

The FM50 twin conformal Canister APR system provides a close-to-face, streamlined design for optimal weapons integration, weight distribution and user comfort. The FM50 is the lowest burden/lowest breathing resistance mask on the market attributable to the twin Canisters. Self-sealing valves allow the user to change Canisters without compromising respiratory protection levels.

- Full range of Outserts available
- Vision Correction System allows for prescription lenses to be mounted inside the mask
- Advanced reflex seal for excellent helmet integration


Available in 3 sizes, the FM50 features a panoramic flexible visor, Electronic Communication Port (ECP), high-flow fail-safe drink device and low profile twin Canisters with a bayonet quick fit connection.



	FM50 APR
	INCLUDES
p/n	Description
	FM50 APR Assembly
72601-53	Faceform
71601-30	FM50 Operator and Maintenance Manual
p/n	Description
71400-1	FM50 APR Assembly LGE
71400-2	FM50 APR Assembly MED
71400-3	FM50 APR Assembly SML

FM50 APR SYSTEM		
INCLUDES		
p/n Description		
FM50 APR		
71601-1-1	FM61 Primary Canisters (Pair)	
70501-156	Clear Outsert Assembly	
71601-30	Operator Manual	
72601-48 APR Carrier (Black)		
p/n	Description	
71450-1	FM50 APR System LGE	
71450-2	FM50 APR System MED	
71450-3	FM50 APR System SML	





FM53 SINGLE PORT APR		
p/n	Description	
72601-250-1	FM53 APR Assembly RH LGE	
72601-250-4	FM53 APR Assembly RH MED	
72601-250-7	FM53 APR Assembly RH SML	
72601-250-10	FM53 APR Assembly RH XS	
72601-250-2	FM53 APR Assembly LH LGE	
72601-250-5	FM53 APR Assembly LH MED	
72601-250-8	FM53 APR Assembly LH SML	
72601-250-11	FM53 APR Assembly LH XS	

FM53 TWIN PORT APR		
72601-250-3	FM53 APR Assembly Twin Port LGE	
72601-250-6	FM53 APR Assembly Twin Port MED	
72601-250-9	FM53 APR Assembly Twin Port SML	
72601-250-12	FM53 APR Assembly Twin Port XS	



FM53 SPECIALIST RESPONDER KIT			
	INCLUDES		
p/n	Description		
	FM53 APR		
70501-156	Clear Outsert Assembly		
70501-158	Blueblocker Outsert Assembly		
72602-2	CBRNCF50		
72606-2	CTCF50 Riot Canister (Sold in packs of 4 -72606-3)		
72601-32	Universal Carrier		
72601-97	Storage Bag		
72601-53	Faceform		

SPECIALIST RESPONDER KIT	
p/n	Description
72601-220	FM53 Specialist Responder Kit RH LGE
72601-221	FM53 Specialist Responder Kit RH MED
72601-222	FM53 Specialist Responder Kit RH SML
72601-223	FM53 Specialist Responder Kit RH XS
72601-224	FM53 Specialist Responder Kit LH LGE
72601-225	FM53 Specialist Responder Kit LH MED
72601-226	FM53 Specialist Responder Kit LH SML
72601-227	FM53 Specialist Responder Kit LH XS

FM53 TWIN PORT SPECIALIST RESPONDER KIT		
72601-228	FM53 Twinport Special Ops Kit LGE	
72601-229	FM53 Twinport Special Ops Kit MED	
72601-230	FM53 Twinport Special Ops Kit SML	
72601-231	FM53 Twinport Special Ops Kit XS	

FM53[™]

The Avon FM53 APR was developed to meet the unique requirements of specialist endusers in the field. The APR, based on the U.S. M50/M53 military technology, provides maximum operational flexibility to counter multiple threat scenarios, including chemical, biological, radiological and nuclear (CBRN) agents, Toxic Industrial Chemicals (TICs), and Toxic Industrial Materials (TIMs).

The FM53 APR is NIOSH certified in the following configurations:

- FM53 APR with CTCF50 Canister Certified under 42 CFR 84
- FM53 APR with CBRNCF50
 Canister Certified under CBRN
 APR Standard Cap1 with Voice
 Projection Unit System as
 standard

Available in four sizes for customized protection to accommodate all operators.

Removable outserts are available to provide additional less lethal ballistic protection, comfortable operation in sunlight, and blue light filtration for sharper sighting.

Fail safe drink system connects directly to Avon CamelBak™ hydration reservoir and canteens

The FM53 APR is certified with several Class 3 NFPA suit ensembles.

Integrated voice communications capability with internal microphone for both radio and voice projection unit use. Additional electronic passthrough for external radio use.

The FM53 specialist kit has been specifically developed with the help of industry experts to provide a total CBRN respiratory solution for the end user. The kit provides a reduced acquisition cost when compared to purchasing the included items separately .

This kit is standard on ST53 SCBA systems.



EZAIP°

The Avon Avon EZAir system has been developed to answer end user's requirements for smaller, lighter and more affordable blown air systems. The traditional benefits of PAPR devices are well known, providing low breathing resistance, cooling air and reduced user burden. However these older systems tend to be heavy, expensive and integrate poorly with protective gear. The Avon EZAir overcomes these downsides with a fully modular and compact unit, designed for optimum integration with existing equipment.

The base system provides protection against biological and riot/crowd control non- lethal munitions. Certified with C50 and FM53 mask with the CTF12 filter to NIOSH 42 CFR part 84, the system comes supplied with all necessary accessories to allow for immediate fielding. A range on 'hot swap' battery packs is available, all delivering greater than 8 hours run time. A close fit, quick release breathing hose is the result of extensive research and the need for better integration with the mask and helmet. The blower carrier allows for either belt or MOLLE mounting to the user. The Avon EZAir produces a lower flow rate than traditional PAPR units, and is classified as a well being device.

- Simple and safe to operate
- Small and discrete
- Extended operational time
- Removable Battery Pack
- Optimized Integration



AVON EZAIR NON LETHAL MUNITIONS SYSTEM			
	INCLUDES		
p/n	Description		
81100-10	Blower		
	Sweep Hose		
	Hose Cover w/zipper		
81100-11	Replaceable Battery Pack		
84100-11	Carrier		
p/n	Description		
81100-19	Avon EZAir NLM System, 36" Hose		
81100-20	Avon EZAir NLM System, 30" Hose		
	AVON EZAIR NLM SYSTEM & FM53 SINGLE PORT APR		
p/n	Description		
81100-28-1	Avon EZAir NLM System, 36" Hose & FM53 RH APR LGE		
81100-28-2	Avon EZAir NLM System, 36" Hose & FM53 RH APR MED		
81100-28-3	Avon EZAir NLM System, 36" Hose & FM53 RH APR SML		
81100-28-4	Avon EZAir NLM System, 36" Hose & FM53 RH APR XS		
81100-29-1	Avon EZAir NLM System, 36" Hose & FM53 LH APR LGE		
81100-29-2	Avon EZAir NLM System, 36" Hose & FM53 LH APR MED		
81100-29-3	Avon EZAir NLM System, 36" Hose & FM53 LH APR SML		
81100-29-4	Avon EZAir NLM System, 36" Hose & FM53 LH APR XS		
81100-30-1	Avon EZAir NLM System, 30" Hose & FM53 RH APR LGE		
81100-30-2	Avon EZAir NLM System, 30" Hose & FM53 RH APR MED		
81100-30-3	Avon EZAir NLM System, 30" Hose & FM53 RH APR SML		
81100-30-4	Avon EZAir NLM System, 30" Hose & FM53 RH APR XS		
81100-31-1	Avon EZAir NLM System, 30" Hose & FM53 LH APR LGE		
81100-31-2	Avon EZAir NLM System, 30" Hose & FM53 LH APR MED		
81100-31-3	Avon EZAir NLM System, 30" Hose & FM53 LH APR SML		
81100-31-4	Avon EZAir NLM System, 30" Hose & FM53 LH APR XS		

AVON EZAIR NLM SYSTEM & C50 TWIN PORT APR		
p/n	Description	
81100-24-1	Avon EZAir NLM System, 36" Hose & C50 Twin Port APR LGE	
81100-24-2	Avon EZAir NLM System, 36" Hose & C50 Twin Port APR MED	
81100-24-3	Avon EZAir NLM System, 36" Hose & C50 Twin Port APR SML	
81100-25-1	Avon EZAir NLM System, 30" Hose & C50 Twin Port APR LGE	
81100-25-2	Avon EZAir NLM System, 30" Hose & C50 Twin Port APR MED	
81100-25-3	Avon EZAir NLM System, 30" Hose & C50 Twin Port APR SML	
AVON EZAIR NLM SYSTEM & FM53 TWIN PORT APR		
ક ા	FM53 TWIN PORT APR	
₽ (PM53 TWIN PORT APR Description Avon EZAir NLM System, 36" Hose &	
p/n 81100-26-1	Description Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR LGE Avon EZAir NLM System, 36" Hose & Warn EZAIr NLM System Sy	
p/n 81100-26-1 81100-26-2	Description Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR LGE Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR MED Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR MED	
p/n 81100-26-1 81100-26-2 81100-26-3	Description Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR LGE Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR MED Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR MED Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR SML Avon EZAir NLM System, 36" Hose &	
p/n 81100-26-1 81100-26-2 81100-26-3 81100-26-4	Description Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR LGE Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR MED Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR SML Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR SML Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR XS Avon EZAir NLM System, 30" Hose & FM53 Twin Port APR XS	
p/n 81100-26-1 81100-26-2 81100-26-3 81100-26-4 81100-27-1	Description Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR LGE Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR MED Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR SML Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR XS Avon EZAir NLM System, 36" Hose & FM53 Twin Port APR LGE Avon EZAir NLM System, 30" Hose & FM53 Twin Port APR LGE Avon EZAir NLM System, 30" Hose & FM53 Twin Port APR LGE	

ST53SD ST-PAPR SINGLE PORT RESPONDER KIT		
	INCLUDES	
p/n	Description	
330003	ST-PAPR	
038022	PAPR Carrier	
089034	Flow Indicator	
180003	LiSO2 Batteries (2)	
033018	Cartridge, AM/CL/SD/HE/CS/CN	
	FM53 Specialist Responder Kit	

ST53SD IO MINUTE ST-PAPR SINGLE PORT RESPONDER KIT	
p/n	Description
SD42001C	ST53SD 4500 psi 10 minute+ST-PAPR+ FM53 Specialist Responder Kit, RH LGE
SD41901C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, RH MED
SD41801C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, RH SML
SD42101C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, RH XS
SD42401C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, LH LGE
SD42301C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, LH MED
SD42201C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, LH SML
SD42501C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, LH XS

ST53 45 MINUTE ST-PAPR SINGLE PORT RESPONDER KIT	
p/n	Description
ST602200103C	ST53 45 minute + ST-PAPR + FM53 Specialist Responder Kit, single port RH LGE
ST602190103C	ST53 45 minute + ST-PAPR +FM53 Specialist Responder Kit, single port RH MED
ST602180103C	ST53 45 minute + ST-PAPR +FM53 Specialist Responder Kit, single port RH SML
ST602210103C	ST53 45 minute + ST-PAPR +FM53 Specialist Responder Kit, single port RH XS
ST602240103C	ST53 45 minute + ST-PAPR +FM53 Specialist Responder Kit, single port LH LGE
ST602230103C	ST53 45 minute + ST-PAPR +FM53 Specialist Responder Kit, single port LH MED
ST602220103C	ST53 45 minute + ST-PAPR +FM53 Specialist Responder Kit, single port LH SML
ST602250103C	ST53 45 minute + ST-PAPR +FM53 Spe- cialist Responder Kit, single port LH XS

	claist responder ray single port 21778	
	ST53 60 MINUTE ST-PAPR SINGLE PORT RESPONDER KIT	
p/n	Description	
ST603200103C	ST53 60 minute + ST-PAPR +FM53 Spe- cialist Responder Kit, single port RH LGE	
ST603190103C	ST53 60 minute + ST-PAPR +FM53 Spe- cialist Responder Kit, single port RH MED	
ST603180103C	ST53 60 minute + ST-PAPR +FM53 Specialist Responder Kit, single port RH SML	
ST603210103C	ST53 60 minute + ST-PAPR +FM53 Specialist Responder Kit, single port RH XS	
ST603240103C	ST53 60 minute + ST-PAPR +FM53 Specialist Responder Kit, single port LH LGE	
ST603230103C	ST53 60 minute + ST-PAPR +FM53 Specialist Responder Kit, single port LH MED	
ST603220103C	ST53 60 minute + ST-PAPR +FM53 Specialist Responder Kit, single port LH SML	
ST603250103C	ST53 60 minute + ST-PAPR +FM53 Spe- cialist Responder Kit, single port LH XS	



ST53SD ST-PAPR TWIN PORT RESPONDER KIT	
p/n	Description
330003	ST-PAPR
038022	PAPR Carrier
089034	Flow Indicator
180003	LiSO2 Batteries (2)
033018	Cartridge, AM/CL/SD/HE/CS/CN
	FM53 Specialist Responder Kit
CTESCO IO MINISTE ET DADO	

TWIN PORT RESPONDER KIT		
p/n	Description	
SD41601C	ST53SD 4500 psi 10 minute +ST-PAPR+ FM53 Specialist Responder Kit, Twin Port LGE	
SD41501C	ST53SD 4500 psi 10 minute+ST-PAPR+FM53 Specialist Responder Kit, Twin Port MED	
SD41401C	ST53SD 4500 psi 10 minute +ST-PAPR+ FM53 Specialist Responder Kit, Twin Port SML	
SD41701C	ST53SD 4500 psi 10 minute +ST-PAPR + FM53 Specialist Responder Kit, Twin Port XS	

TWIN PORT RESPONDER KIT	
p/n	Description
ST602160103C	ST53 45 minute + ST-PAPR + FM53 Specialist Responder Kit, Twin Port LGE
ST602150103C	ST53 45 minute + ST-PAPR + FM53 Specialist Responder Kit, Twin Port MED
ST602140103C	ST53 45 minute + ST-PAPR +FM53 Specialist Responder Kit, Twin Port SML
ST602170103C	ST53 45 minute + ST-PAPR +FM53 Specialist Responder Kit, Twin Port XS

ST53 60 MINUTE ST-PAPR TWIN PORT RESPONDER KIT	
p/n	Description
ST603160103C	ST53 60 minute + ST-PAPR + FM53 Specialist Responder Kit, Twin Port LGE
ST603150103C	ST53 60 minute + ST-PAPR + FM53 Specialist Responder Kit, Twin Port MED
ST603140103C	ST53 60 minute + ST-PAPR + FM53 Specialist Responder Kit, Twin Port SML
ST603170103C	ST53 60 minute +ST-PAPR +FM53 Specialist Responder Kit, Twin Port XS

ST-PAPR[™]

The ST-PAPR module delivers total operational flexibility to the end user and is an option for the ST53 SCBA. The patented design allows for the SCBA quick connect to be attached directly to the PAPR unit and allows the wearer to transition from powered air to SCBA mode without loss of protection or additional parts.

Certified by NIOSH as a stand alone PAPR unit system with the FM53 APR, the unit can be configured to deliver a combination system.

- The ST- PAPR has a remote on-off switch enabling the ST- PAPR to be easily switched on and off.
- Minimum flow rate of 115 lpm.
- Lithium Sulfur Dioxide battery option with a minimum 7 hour battery life.
- Operator replaceable spare parts available, easy to maintain with access to key components.
- User can 'hot-swap' battery if required without contamination (common batteries with the C420 PAPR)
- Inline canister configuration designed to be low profile when strapped to the ST53 cylinder or ST53SD system.
- With quick-connect for SCBA feature, ST53 or ST53SD systems both attach to the unit to provide a single hose connection to the APR. Designed for specialist users (shooters) who need to use a single sided Canister FM53 APR.
- The integrated second stage regulator allows for a single hose connection to the FM53 APR. Unique to the ST-PAPR, this feature ensures that the FM53 APR retains its low profile cheek for weapon sighting.



C420^{*}

The C420 is a powerful, comfortable and military proven system, that filters CBRN and other contaminants from ambient air providing a constant Canistered airflow greater than 115 lpm. This constant air flow in the APR reduces the physical burden of inhalation resistance and pressure respirators.

Available with 8 hour Lithium Sulfur Dioxide Battery, unique 8 hour Rechargeable Lithium Ion Battery, and NiMH variant rechargeable battery.

The C420 is NIOSH CBRN certified with both Avon's CBRN FM12 APR and C50 APRs.

- Choice of Two (2) Avon class leading respirators
- 8 hours of increased protection in hazardous environments
- Ideal for prolonged respirator wear in hot climates
- Delivers cooling, fresh air





C420 PAPR BLOWER KIT		
p/n	Description	
p/11	'	
	Blower Unit	
70501-215	70" Decon Belt	
70501-214	36" CBRN hose	
70501-219	Flow Indicator	
70501-84	User Instructions	

C420 PAPR BLOWER KIT		
p/n	Description	
70501-245	C420 PAPR Blower Kit	
C420 PAPR W/C50 CBRN APR		
_	TEOT THE WYESO EDING ALL	
p/n	Description	
	,	
p/n	Description	

ST CONFIGURATION





MODULE 2 ST53 SCBA



MODULE 3 ST-PAPR KIT



ST53SD







ST53











ST-PAPR short duration







ST53°

The ST53 combines Avon Protection Systems' FM53 APR with innovative modular breathing apparatus technology to provide positive pressure SCBA and-or PAPR capability for specialist applications. The ST53 system provides the operator with total flexibility to select the necessary level of protection quickly while continuing to operate effectively.

The standard ST53 uses a low profile back frame to mount a range of 4500 PSI lightweight carbon cylinders with black stealth covers, available in 30, 45 and 60 minutes durations.

Cylinder Content Monitoring
The ST53 backframe option
includes a remotely accessible,
chest mounted pressure gauge
for monitoring of pressure and a
whistle for end of service alarm
(which has the option to be
disabled if required).

Compact Demand Valve (CDV)
The compact chemically
hardened demand valve provides
constant positive pressure. The
CDV is attached to the FM53 APR
via the standard 40 mm STANAG
thread.

With the option to mount on either side of the APR, it is unobtrusive and allows excellent integration with weapons and other equipment.

With the ST-PAPR the integrated CDV enables the user to switch instantly from powered air to positive pressure SCBA mode when required.

When the ST53 is used with Module 3 (ST-PAPR) the CDV is simply removed via a quick disconnect and the SCBA air line connected directly to the ST-PAPR module that contains an internal CDV

Stealth Features

Designed with stealth applications in mind including non-reflective black components and a warning whistle which can be silenced.



NIOSH approved in SCBA mode only.*

*NIOSH does not currently approve combination respirators.



ST53 TWIN PORT RESPONDER KIT			
	INCLUDES		
ST53	ST53		
FM53 Specialist Responder Kit			
ST53 45 MINUTE TWIN PORT RESPONDER KIT			
p/n	Description		
ST602160103A	ST53 45 minute +FM53 Specialist Responder Kit, Twin Port LGE		
ST602150103A	ST53 45 minute +FM53 Specialist Responder Kit, Twin Port MED		
ST602140103A	ST53 45 minute +FM53 Specialist Responder Kit, Twin Port SML		
ST602170103A	ST53 45 minute +FM53 Specialist Responder Kit, Twin Port XS		
ST53	ST53 60 MINUTE TWIN PORT RESPONDER KIT		
p/n	Description		
ST603160103A	ST53 60 minute +FM53 Specialist Responder Kit, Twin Port LGE		
ST603150103A	ST53 60 minute +FM53 Specialist Responder Kit, Twin Port MED		
ST603140103A	ST53 60 minute +FM53 Specialist Responder Kit, Twin Port SML		
ST603170103A	ST53 60 minute +FM53 Specialist Responder Kit, Twin Port XS		

ST53 SINGLE PORT RESPONDER KIT		
INCLUDES		
ST53		
FM53 Specialist I	Responder Kit	
ST53 45 MINUTE SINGLE PORT		
p/n	RESPONDER KIT Description	
ST602200103A	ST53 45 minute +FM53 Specialist Responder Kit, RH LGE	
ST602190103A	ST53 45 minute +FM53 Specialist Responder Kit, RH MED	
ST602180103A	ST53 45 minute +FM53 Specialist Responder Kit, RH SML	
ST602210103A	ST53 45 minute +FM53 Specialist Responder Kit, RH XS	
ST602240103A	ST53 45 minute +FM53 Specialist Responder Kit, LH LGE	
ST602230103A	ST53 45 minute +FM53 Specialist Responder Kit, LH MED	
ST602220103A	ST53 45 minute +FM53 Specialist Responder Kit, LH SML	
ST602250103A	ST53 45 minute +FM53 Specialist Responder Kit, LH XS	
ST53 (50 MINUTE SINGLE PORT	
p/n	RESPONDER KIT Description	
ST603200103A	ST53 60 minute +FM53 Specialist Responder Kit, RH LGE	
ST603190103A	ST53 60 minute +FM53 Specialist Responder Kit, RH MED	
ST603180103A	ST53 60 minute +FM53 Specialist Responder Kit, RH SML	
ST603210103A	ST53 60 minute +FM53 Specialist Responder Kit, RH XS	
ST603240103A	ST53 60 minute +FM53 Specialist Responder Kit, LH LGE	
ST603230103A	ST53 60 minute +FM53 Specialist Responder Kit, LH MED	
ST603220103A	ST53 60 minute +FM53 Specialist Responder Kit, LH SML	
ST603250103A	ST53 60 minute +FM53 Specialist Responder Kit, LH XS	



ST53SD 480 LITER TWIN PORT RESPONDER KIT **INCLUDES** ST53SD + Carrier FM53 Specialist Responder Kit ST53SD 4500 psi 10 minute + FM53 SD41601A Specialist Responder Kit, Twin Port LGE ST53SD 4500 psi 10 minute + FM53 SD41501A Specialist Responder Kit, Twin Port MED ST53SD 4500 psi 10 minute + FM53 SD41401A Specialist Responder Kit, Twin Port SML ST53SD 4500 psi 10 minute + FM53 SD41701A Specialist Responder Kit, Twin Port XS

ST53SD 10 MINUTE SINGLE PORT RESPONDER KIT		
INCLUDES		
Description		
ST53SD + Carrier		
FM53 Specialist	Responder Kit	
p/n	Description	
SD42001A	ST53SD 4500 psi 10 minute + FM53 Specialist Responder Kit, RH LGE	
SD41901A	ST53SD 4500 psi 10 minute + FM53 Specialist Responder Kit, RH MED	
SD41801A	ST53SD 4500 psi 10 minute + FM53 Specialist Responder Kit, RH SML	
SD42101A	ST53SD 4500 psi 10 minute + FM53 Specialist Responder Kit, RH XS	
SD42401A	ST53SD 4500 psi 10 minute + FM53 Specialist Responder Kit, LH LGE	
SD42301A	ST53SD 4500 psi 10 minute + FM53 Specialist Responder Kit, LH MED	
SD42201A	ST53SD 4500 psi 10 minute + FM53 Specialist Responder Kit, LH SML	
SD42501A	ST53SD 4500 psi 10 minute + FM53 Specialist Responder Kit LHXS	

ST53SD 480 LITER ST-PAPR TWIN PORT RESPONDER KIT	
INCLUDES	
ST53SD + Carrier	
FM53 Specialist Responder Kit	
p/n	Description
SD41601C	ST53SD 4500 psi 10 minute +ST-PAPR+ FM53 Specialist Responder Kit, Twin Port LGE
SD41501C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, Twin Port MED
SD41401C	ST53SD 4500 psi 10 minute +ST-PAPR+ FM53 Specialist Responder Kit, Twin Port SML
SD41701C	ST53SD 4500 psi 10 minute +ST-PAPR + FM53 Specialist Responder Kit, Twin Port XS

ST53SD IO MINUTE ST-PAPR SINGLE PORT RESPONDER KIT		
INCLUDES		
Description		
ST53SD + Carrier		
FM53 Specialist Responder Kit		
p/n	Description	
SD42001C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, RH LGE	
SD41901C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, RH MED	
SD41801C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, RH SML	
SD42101C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, RH XS	
SD42401C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, LH LGE	
SD42301C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, LH MED	
SD42201C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, LH SML	
SD42501C	ST53SD 4500 psi 10 minute+ST-PAPR + FM53 Specialist Responder Kit, LH XS	

Short duration variant ST53SD, provides a belt or harness carry option and an approximate 10 minute duration air cylinder. Compatible with the ST-PAPR, the ST53SD meets the unique requirements of end users in short-duration tactical operations

The ST53SD provides the option to have a pressure gauge attached directly on the regulator body or to not have one.

With the ST-PAPR the integrated Compact Demand Valve (CDV) enables the user to switch instantly from powered air to positive pressure SCBA mode when required.

The CDV is attached to the APR via the standard 40 mm thread connection.

The simplicity, lower cost of ownership and reduced weight make the ST53SD an ideal solution to provide protection in unknown IDLH scenarios where a quick exit can be achieved.

Specialist Responder Kit, LH XS

NHI5[™]

The NH15 Escape Emergency Hood is designed specifically for users in an emergency incident. The world's smallest NIOSH CBRN Cap 1(15 minutes) escape device is available in large, regular and extra small sizes. Not requiring maintenance or annual fit testing, the unit is designed for 5 years shelf life. Supplied in a black carrier that can be belt or shoulder mounted.

- Don in less than 20 seconds
- 15 minutes of protection
- 5 year shelf life
- Compact for quick access
- Close fit and comfortable to wear

The Training Hood is used by training teams, staff and large groups to demonstrate the proper use, donning and doffing of the NH15 hood. This training hood is for demonstration use only.

NH15 H2S Filter Escape Hood Respirator. The most compact industrial H2S filter escape hood respirator provides protection for a minimum 15 minutes to allow sufficient time to evacuate from a contaminated area. The streamlined design minimizes the overall footprint while the hood provides a clear range of vision to the wearer.





NHI5 ESCAPE HOOD (WITH STANDARD CARRIER)	
p/n	Description
75027-104-A-AC	NH15 CBRN Escape Hood (Extra Small)12 to 13 inches
75027-100-A-AC	NH15 CBRN Escape Hood (Regular) 13 to 18 inches
75027-107-A-AC	NH15 CBRN Escape Hood (Large) 18-22 inches

NHIS GROUP USER KIT (IO PEOPLE)	
p/n	Description
72601-219	NH15 Group User Kit (10 people)

NHIS H ₂ S ESCAPE HOOD (WITH STANDARD CARRIER)	
p/n	Description
75027-104-B	NH15 H ₂ S CBRN Escape Hood (Extra Small)12 to 13 inches
75027-100-B	NH15 H ₂ S CBRN Escape Hood (Regular) 13 to 18 inches
75027-107-B	NH15 H ₂ S CBRN Escape Hood (Large) 18-22 inches



TRAINING HOOD	
p/n	Description
75027-104T-A-AC	Training Hood (Extra Small)
75027-100T-A-AC	Training Hood (Regular)
75027-107T-A-AC	Training Hood (Large)



CRSI5			
p/n	Description		
600601	CRS15, 1 person (Regular)		

CRSI5

The CRS15 pack provides respiratory and touch protection from a broad range of CBRN, TIC Threats and all current Riot Control Gases combined with the ability for the user to perform immediate decontamination.

The equipment is discreetly contained in a rucksack enabling the user to respond rapidly to an incident or event. Close liaison with the end user ensures the CRS15 pack contents are tailored exactly to meet individual requirements.

Avon's CRS15 pack is suitable for the following users:

- First Responders
- High Net Worth Individuals
- Strategically Important Individuals
- Security Teams
- CP Escorts/Teams
- Non Specialist First Response
- Media
- NGOs
- Corporate
- Non Specialist Government eg. Government Staff, DFiD etc
- Embassy Staff

CRS15 Contents:

- Full Respiratory and Eye Protection
- Touch Protection
- Disposable Coverall
- Biological Decontamination
- Chemical/TIC Decontamination
- Rucksack
- Instruction Card
- Disposal Bags
- Protective Overboots

FILTRATION - CANISTERS



CBRNF12



NIOSH certified as a CBRN Cap 1 canister for use with the Avon FM12. This Canister protects against all particulate hazards including dust, mist, fume, bacteria and virus along with all NIOSH specified CBRN gases and other vapors including nerve, blood, choking and blister agents.

PC50	C50	FM50	FM53	Avon EZAir

Pack of 4 70010-23-2



AM/CL/SD/HE/CS/CN



NIOSH certified as a CartridgeAM/CL/SD/HE/CS/CN for use with the Avon ST-PAPR. This Canister protects against all particulate hazards including dust, mist, fume, bacteria and virus along with all NIOSH specified CBRN gases and other vapors including nerve, blood, choking and blister agents.

PC50	C50	FM50	FM53	STPAPR

Pack of 4 033018



CBRNCF50



NIOSH Certified as a CBRN Cap 1 Canister for use with the Avon C50, FM12, and FM53 protects against chemical and biological warfare agents in aerosol, liquid and vapor form. The filter has a Threaded Converter Piece (TCP) that when removed creates a filter with a unique conformal shape providing a low profile, close fit with the mask. Once the TCP is removed the canister becomes a CBRNCF50i. The CBRNCF50i is only approved to NIOSH Cap 1 when fitted to Avon masks. It provides effective protection against all the gaseous agents specified in the NIOSH CBRN standard, as well as excellent performance against a wider range of both chemical warfare agents and Toxic Industrial Chemicals (TICs). A particulate filter element exceeding the requirements of NIOSH 42CFR84 P100 and EN 14387 (P3) is incorporated, ensuring effective performance against all dusts, mists, fumes, biological agents (bacteria, virus, fungal spores etc), including radioactive dusts.

PC50 C50 FM50 FM53 C420


72602-2



CTCF50



The Avon CTCF50 Filter is a low profile combination filter containing a pleated high-efficiency filter element for removal of aerosols, particulate matter, smoke fumes and a carbon bed for the removal of vapors that may be released from trapped particles. It is specifically designed for removal of riot control agents and tear gases including CS, CN and OC pepper spray.



Pack of 4 72606-3

FILTRATION - CANISTERS



CTF12 Riot Agent Filter



NIOSH certified 42 CFR part 84 CN-CS-P100 with the Avon masks Approved for all particulate hazards including dust, mist, fume, bacteria and viruses, plus riot agents.

PC50	C50	FM50	FM53	Avon EZAir

71510-2



FM61 Primary Canister Pair

Low profile conformal Canister with bayonet quick fit connector for use only with the Avon FM50 APR. General purpose military NBC performance. Provides protection against chemical, biological and radiological warfare agents in accordance with NATO requirements. Also for certain TIC-TIM's such as chlorine, hydrogen sulphide, sulphur dioxide and organic vapors with a boiling point above 65°C.

PC50	C50	FM50	FM53	Avon EZAir

71601-1-1

CANISTER SELECTION MATRIX

FILTER •••	CTCF50	CTFI2 Riot	CBRNF12	CBRNCF50	FMGI
External Approvals	NIOSH	NIOSH	NIOSH	NIOSH	
Classification	CS/CN/P100	CS/CN/P100	CBRN Cap1	CBRN Cap1	Mil Spec
Protection	Riot Agents Odor Particulate	Riot Agents Odor Particulate	Riot Agents Odor Particulate CBRN Agents NBC Agents ABEK Agents TICS	Riot Agents Odor Particulate CBRN Agents NBC Agents ABEK Agents TICS	Riot Agents Odor Particulate CBRN Agents NBC Agents ABEK Agents TICS
Weight (typical)	154 g	200 g	332 g	356 g	156 g
Breathing Resistance (typical)	15 mm H ₂ O at 85 l/min	32 mm H ₂ O at 85 l/min	41 mm H ₂ O at 85 l/min	45 mm H ₂ O at 85 l/min	22 mm H ₂ O at 42.5 l/min
Packing	Foil Bag	Plastic Wrap	Foil Bag	Induction Welded Package	Induction Welded Package
Shelf Life (if left in packaging)	5.5 years	5 years	5 years	5.5 years	5 years
Filter Body Style	Conformal	Conventional	Conventional	Convertible	Conformal*
Filter Thread Type	40 mm	40 mm	40 mm	40 mm	Bayonet

^{*}This filter has a bayonet fit specific to the FM50 mask and must be used as a pair

SUITABLE PROTECTION AG	AINST:				
Ammonia			•	•	0
Arsine			•	•	•
Asbestos	•	•	•	•	•
Bacteria	•	•	•	•	•
Benzene			•	•	•
Blister agent			•	•	•
Blood agent			•	•	•
Bromine			•	•	•
Carbon Dioxide					
Carbon Disulphide			•	•	•
Carbon Monoxide					
Carbon Tetrachloride			•	•	•
Chlorine			•	•	•
Chlorine Dioxide			•	•	•
Chloroacetophenone (CN)	•	•	•	•	•
Chloropicrin			•	•	•
o-Chlorobenzylidene Malononitrile (CS)	•	•	•	•	•
Cyanogen			•	•	•
Cyanogen Chloride (CK)			•	•	•
Cyclohexane			•	•	•
Fluorine			•	•	•

CANISTER SELECTION MATRIX

FILTER •••	CTCF50	CTFI2 Riot	CBRNFI2	CBRNCF50	FM6I
SUITABLE PROTECTION AG	AINST:				
Formaldehyde			•	•	•
Hydrogen Chloride			•	•	•
Hydrogen Cyanide (AC)			•	•	•
Hydrogen Fluoride			•	•	•
Hydrogen Sulfide			•	•	•
Lewisite			•	•	•
Methylamine			•	•	0
Methyl Bromide			•	•	•
Methyl lodide			•	•	•
Mustard (HD)			•	•	•
Nerve agent			•	•	•
Nitrogen Dioxide			•	•	•
Nuisance dusts	•	•	•	•	•
Nuisance odours	•	•	•	•	•
Oleoresin Capsicum (OC, pepper gas)	•	•	•	•	•
Organic vapours w/ boiling point >65°C			•	•	•
Particulates	•	•	•	•	•
Phosgene			•	•	•
Phosphine			•	•	•
Radioactive particulates	•	•	•	•	•
Sarin (GB)			•	•	•
Soman (GD)			•	•	•
Sulphur Dioxide			•	•	•
Tabun (GA)			•	•	•
Toluene			•	•	•
Virus	•	•	•	•	•
VX			•	•	•
Xylene			•	•	•

	LEGEND		▲ WARNINGS
Conformal 40mm Stanag Thread	Filter Body Style Standard 40mm Stanag Thread	Filter Effective Limited Effectiveness Contact Avon Protection for additional information	 These filter recommendations are for guidance only. It is assumed that some filters are used only once and then replaced. Respirator filters must be selected by a competent person following a suitable and sufficient risk assessment. Filters must be used in accordance with appropriate guidelines, regulations or doctrine applied in line with the legislation of the country of application, inappropriate use could result in injury or death. Filters must be stored in accordance with Avon's user instructions. The incident commander must establish a filter change schedule based on a suitable and sufficient risk assessment. Failure to do so may result in filter breakthrough and consequent injury or death. Contact Avon for assistance. Do not use filtering respirators in oxygen deficient atmospheres (<19.5%) or in poorly ventilated spaces.
.c starting triffedu	Starlag Tiricad		Avon conformal filters for use on specific Avon masks only. Filters may not seal with other products leading to serious injury or death.

COMMUNICATION



FM53 Voice Projection Unit

The VPU is designed for the FM53 APR to allow non-obstructed weapon sighting and easier operation. The VPU is attached to the front of the VREU (Variable Exhalation Resistance Unit) and can be removed to allow for APR exhalation resistance changes. The pass through lead provides an interface to the APR connector and houses a second connector to attach additional communication equipment while the VPU is being worn. The VPU must be used with the Voice Projection Unit Microphone (72601-16) or Microphone Assembly (72601-17). Additional communication kits are available on request. The unit requires a single Li-lon battery -CR123 (not supplied), the microphone is powered by the VPU.

PC50	C50	FM50	FM53

72601-13



Voice Projection Unit

The Voice Projection Unit (VPU) clips to the front of the C50 and FM50 APR without any need for special tools and is designed to amplify the APR wearer's voice. The VPU must be used with the Voice Projection Unit Microphone (71601-12) or Microphone Assembly (71601-13). Once fitted the VPU is securely attached and still allows for weapon firing. The unit requires two 2 AAA batteries (not supplied). The microphone is powered by the VPU.

PC50	C50	FM50	FM53

70501-229



FM53 Voice Projection Unit w/Microphone Assembly

Complete communication kit for FM53 mask. Contains Voice Projection Unit (72601-13) and Microphone Assembly (72601-17), battery not included.

PC50	C50	FM50	FM53

72601-15

COMMUNICATION



Voice Projection Unit w/Microphone Assembly

Complete communication kit for C50 and FM50 APRs. Contains Voice Projection Unit (70501-229) and Microphone Assembly (71601-13), batteries not included.

PC50	C50	FM50	FM53

71601-11



Microphone Assembly

To be used in conjunction with the FM50-C50 VPU (70501-229) only. Supplied with a 150 Ohm Dynamic Microphone for use with external communication equipment. Use Communication Lead (70501-167 or 70501-167-1) for connection, additional lead available through customer service.

PC50	C50	FM50	FM53

71601-13



Elevated Tube Imic Assembly

To be used in conjunction with the FM53 VPU (72601-13) only. Supplied with a 150 Ohm Dynamic Microphone for use with external communication equipment. Use Communication Lead (70501-167 or 70501-167-1) for connection.

PC50	C50	FM50	FM53
1 030	C30	111150	111133

601022



FM53 Microphone Assembly

To be used in conjunction with the FM53 VPU (72601-13) only. Supplied with a 150 Ohm Dynamic Microphone for use with external communication equipment. Use Communication Lead (71601-14) for connection.

PC50	C50	FM50	FM53

72601-17

COMMUNICATION



Dynamic Microphone

Microphone allows APR to be used with external communication equipment. Can be fitted to VPU Microphones (72601-16 & 71601-12) and Microphone Adapter (72601-14).

PC50	C50	FM50	FM53

72601-20



FM53 Voice Projection Unit Microphone

Internal microphone for use on FM53 APRs only. To be used in conjunction with Voice Projection Unit (72601-13). Black in color.

PC50	C50	FM50	FM53

72601-16



Voice Projection Unit Microphone

Internal microphone for use on C50 and FM50 APRs only. To be used in conjunction with Voice Projection Unit (70501-229). Grey in color.

PC50	C50	FM50	FM53

71601-12



Microphone Adapter



20) and other Mil Spec microphones. For use with external communication equipment only. Green in Color.

PC50	C50	FM50	FM53

72601-14



Communications Lead

Adapter required when using Dynamic Microphone (72601-20) and other Mil Spec NIOSH certified accessory (with C50 APR) to provide connection with external radio systems. Supplied with non-terminated end to allow for connector of choice to be added. Adjustable rubber lanyard and robust metal clip included for attachment and improved integration with protective clothing.

PC50	C50	FM50	FM53

15" Length 70501-167 25" Length 70501-167-1

VISION



Clear Outsert Assembly

Flexible polycarbonate outsert that simply attaches to 50 and 53 series APRs to provide additional ballistic and scratch resistance in extreme environments. Optically correct and distortion free, the outsert can be fitted and removed by the user while the APR is being worn. Provided with Outsert Pouch (72601-28) for storage and lens cleaning.

PC50	C50	FM50	FM53

70501-156



Sunlight Outsert Assembly

Additional protection against high level UV light and flash flares is provided by the sunlight outsert. Constructed from the same material as the clear outsert (70501-156) for improved ballistics and abrasion resistance. Provided with Outsert Pouch (72601-28) for storage and lens cleaning.

PC50	C50	FM50	FM53

70501-157



BlueBlocker Outsert Assembly

Designed for specialist use to improve weapon sighting, the BlueBlocker outsert delivers sharper images by Canistering out specific light wavelengths. Constructed from the same material as the clear outsert (70501-156) for improved ballistics and abrasion resistance. Provided with Outsert Pouch (72601-28) for storage and lens cleaning.

PC50	C50	FM50	FM53

70501-158



Mirrored Outsert Assembly

Provides protection against UV light and improves contrast and depth perception. In addition to hiding the wearer's eyes while reflecting the surroundings they provide a psychological advantage in a threat situation. Provided with Outsert Pouch (72601-28) for storage and lens cleaning.

PC50	C50	FM50	FM53

71014-14

VISION



Breach Outsert Assembly

Shade 5 Outsert designed to provide eye protection for Specialist Operators while deploying cutting torches during their mission. Provided with Outsert Pouch (72601-28) for storage and lens cleaning.

PC50	C50	FM50	FM53

72501-688



Laser Outsert Assembly

Specialist accessory for the removal of harmful laser wavelengths commonly produced by laser sighted weapons. Constructed from the same material as the clear outsert (70501-156) for improved ballistics and abrasion resistance. Provided with Outsert Pouch (72601-28) for storage and lens cleaning.

PC50	C50	FM50	FM53

72601-29



Vision Correction Assembly

The Avon Vision Correction Assembly allows prescription lenses to be fitted to all Avon 50 Series masks. The field-proven flexible design allows the Vision Correction Assembly to be folded inside the air purifying respirator. Lens height can be quickly and easily adjusted by the user. ESS provides Avon 50 Series customers with a web-based professional Rx-filling service at competitive rates. ESS utilizes high quality, shatterproof corrective lenses appropriate for use in hazardous environments. For added safety, it is recommended that the optional Avon Clear Outsert (#70501-156) be worn with 50 Series protective masks. Order Online Only: http:// www.avon-protection.com/vision-correction.htm

PC50	C50	FM50	FM53

70501-155

STORAGE AND CARRIERS













Faceform

Replacement storage accessory for all 50 and 53 series APRs. For prolonged APR storage (>1 month) it is recommended that the faceform is secured to APR to prevent any possibility of face seal distortion.

PC50	C50	FM50	FM53

72601-53

Storage Bag

Storage bag for C50 and FM53. Simple zip closure and carry handle allow for quick APR access in an emergency.



C50 Carrier **70501-227** FM53 Carrier 72601-97

APR Carrier

This US DoD issued carrier provides a complete storage solution for 50 and 53 series APRs with multiple mounting positions. Designed to carry the APR, Canister, spare Canister, manual, 2 outserts and VPU. Carrier can be leg, waist or MOLLE mounted. Internal secondary sleeve prevents dust ingress in more extreme environments. Available in green or black.

PC50	C50	FM50	FM53

Green 72601-47 Black **72601-48**

Universal Carrier

The universal carrier is designed to hold all Avon APRs with Canister attached. Features include belt mount and MOLLE mount.

PC50	C50	FM50	FM53

72601-32

Individual Equipment Carrier

This accessory compliments the APR Carrier and provides additional storage for accessories. Designed with MOLLE attachment, this equipment carrier offers multiple mounting positions and flexible storage options. Available in green or black.

PC50	C50	C50 FM50	FM53

Black 72601-52 72601-51 Green

Extension Strap

To be used in conjunction with the APR Carrier to provide additional strap length for larger wearers.

PC50	C50	FM50	FM53

Black 72601-50 72601-49 Green

HYDRATION



CBR 50i 3L Reservoir

Designed specifically for Avon CBRN APRs, CamelBak's fifth generation Chem Bio Reservoir™ with DuraFlex Barrier™ Technology resists penetration of live chemical and biological warfare agents in addition to common toxic industrial chemicals and materials. The CBR50i Reservoir is lightweight, durable, flexible and provides taste-free fluids on demand. Designed to replace conventional hydration systems for everyday use and all CBRN applications. Not currently certified for use in Hot Zones.

C50	FM50	FM53

90818

3L ThermoBak Long Neck carrier Black

Basic carrier to hold 3 liter CBR50i reservoir.

C50	FM50	FM53


90-41112



Protective APR Adapter

Type A

Adapter fits S10, FM12, FM50 and FM53 protective APRs. Not required for CBR50i Reservoir.



90662



Cleaning Kit

(incl 2 Cleaning Tablets)

Includes two brushes, two cleaning tablets, and reservoir dryer. Reservoir dryer compatible with the Long-Neck and OMEGA® reservoirs (not compatible with baffled reservoirs).

C50	FM50	FM53

60112



Reservoir Dryer

Accessory that locates inside CBR50i reservoir to allow for effective drying after cleaning.

C50	FM50	FM53

90091



Brush Set

Includes brushes for cleaning reservoir and drinking tube.

C50	FM50	FM53	90081



Big Bite Valve Cover Black Replacement bite piece for use with

CBR50i reservoir.

C50	FM50	FM53

60091



Water Canteen Cap

Cap is designed to fit on most 40mm STANAG thread canteen devices. Provided with strap to retain cap on canteen and protect connection from dirt ingress.

C50	FM50	FM53

72601-62

MAINTENANCE TOOLS



APR Dryer

The R12 APR Dryers are specifically designed for drying Avon Protection APRs, and is the only dryer to effectively dry both the APR and the drink tube circuit. Although the dryer is made for Avon Protection APRs, it will also dry any SCBA face APR. The dryer has a 3 way energy management switch and 24hr timer, as well as an 8' long 3 prong cord. The face APRs are placed upside down; on the dryer for drying, water then collects away from nose cup and visor where air is directed into the face area and onto the webbing. The R12 also has an attachment to dry the drinking tube of the APR through a connection port on the dryer. The Avon Wall Mounted R12 APR dryer is floor supported, and wall mounted. The Avon Portable R12 APR dryer is floor supported and on wheels for easy movement.

R12 Wall Mounted APR Dryer, 110V, CSA	89962-10-1
R12 Wall Mounted APR Dryer, 220V, CSA	89962-10-2
R12 Portable APR Dryer, 110V, CSA	89962-11-1
R12 Portable APR Dryer, 220V, CSA	89962-11-2



Avon 50 Series APR DCM Cleaning Kit

This DCM cleaning kit aids in the cleaning of the electrical connectors on both the microphone assembly and the Drinks Comms Module (DCM) located in the chin of the respirator. The components in this kit were specifically selected to aid the user in maintaining the communications accessories in the best possible condition.

600844

SPECIAL TOOLS



Sizing Tool

The Avon sizing tool is simple to use and provides a quick method for initial sizing of APR to wearer. It does not replace the requirement to perform a quantitative fit test as outlined by OSHA and NIOSH.

PC50	C50	FM50	FM53

71601-31

72601-55

Canister Mount Plug Tool

Allows twin port APRs to be converted to accept Canisters on either side. Must be used in conjunction with Canister Mount Plug (72601-56). The conversion must be carried out by a trained Level 2 technician and a APR leak test performed afterwards.

PC50	C50	FM50	FM53

Pack of 5 72601-73



APR SPARE PARTS



Nosecup

Replacement nosecups for FM53 APRs only. Made from comfortable silicone, the interchangeable design allows wearers to customize their APR for an optimized fit. Nosecup size will only fit APR size above or below sized part (e.g. Medium APR will accept a Small, Medium & Large nosecups only). Refer to maintenance manual for nosecup removal.



C50	FM50	FM53

Inlet-Outlet Disk Valve

Low resistance inhalation and exhalation valves for 50-series Avon APRs. Made from durable polyisoprene rubber, the valves require minimum maintenance.

> (pack of 10) 71601-169



XL	72601-8
LGE	72601-9
MED	72601-10
SML	72601-11
XS	72601-12



C50	FM50	FM53

External Drink Tube and Drink Coupler Assembly

Replacement external drink tube and drinking coupler for FM53 and FM12 APRs only. Must be fitted in accordance to maintenance manual by a Level 2 Technician.

> (pack of 5) 72601-61



C50	FM50	FM53

Self-Sealing Disk Valve


Replacement one way valve for FM50 APRs only. Made from silicone, the valve prevents ingress of contaminates to the APR while changing out Canisters by automatically sealing the airway into the APR until a new Canister is refitted.

> (pack of 10) 71601-32



Internal Drink Tube

Replacement internal drinking part for APR hydration. 50 series tubes can be cut to length. Must be fitted according to maintenance procedure and parts fitted must be free of grease and dirt. Sold in packs of 5.



(pack of 5) 70501-163 (pack of 5) 72601-58



Disk Valve

Low resistance inhalation and exhalation valves for Avon FM53 and FM12 APRs. Made from durable polyisoprene rubber, the valves require minimum maintenance. For use with FM53 as an inhalation valve ONLY.

(pack of 10) 71601-5

APR SPARE PARTS



Gasket

CBRN hardened rubber sealing gasket for Canister interface. Inspect regularly and replace immediately if damaged or excessive compression set in material is visible.

PC50	C50	FM50	FM53

(pack of 10)	70501-168
(pack of 5)	72601-137
(Twin Port)	SP7009-15-1



FM50 Air Deflector

Replacement internal air deflector(s) that provide directed air inside APR to prevent visor fogging and assist with cooling affect.

(pack of 2)	71601-33
-------------	----------



FM53 Air Deflector

Replacement internal air deflector(s) that provide directed air inside APR to prevent visor fogging and assist with cooling affect.



NIOSH (pack of 5) 72601-4



FM53 Valve Cassette Assembly

Replacement negative and positive exhalation valve assembly for FM53 APR only. Must be used in conjunction with Valve Cassette Assembly Tool (72601-7) and replacement O-Rings (72601-2). Procedures outlined in FM53 Maintenance Manual (72601-59).


PC50	C50	FM50	FM53

72601-6



Air Deflector

Replacement internal air deflector(s) that provide directed air inside APR to prevent visor fogging and assist with cooling affect.



(pack of 5) 70501-164



Front Module Cover

Replacement front cover for C50 and FM50 APRs provides essential cover for exhale valve and communication port. Replace immediately if damaged. To remove front cover, turn drink level to the up position and remove front cover from APR.

PC50	C50	FM50	FM53

(pack of 5) 70501-162

APR SPARE PARTS



C50 FM50

O-Ring

Part must be used when replacing Valve Cassette Assembly (72601-6) on FM53 APR. Refer to maintenance manual (72601-59) for details.

> (pack of 10) 72601-2



C50 FM50 FM53

Canister Mount Plug

Replacement Canister mount plug for twin port APRs only. Must be used in conjunction with Canister Mount Plug Tool (72601-57) and correct sealing Gasket.

(pack of 5)

72601-56



Head Harness

Replacement head harness for Avon APRs only.



70501-159 (pack of 5)

(single) 71601-23



FM53 VREU Lever

Lever for FM53 APR VREU (Variable Resistance Exhalation Unit). The lever attaches to the FM53 Valve Cassette Assembly and allows APR to be easily switched from positive pressure to negative pressure mode without removing the VPU (Voice Projection Unit). The FM53 Valve Cassette Assembly is sold separately.

PC50	C50	FM50	FM53

(pack of 5) 72601-136



Buckle Components

Replacement buckle set for C50 and FM50 APRs only. To be exchanged by qualified personnel only.

PC50	C50	FM50	FM53

70501-160 (pack of 5)



TSI Portacount Adapter

The fit test adapters enable individuals to be quantitatively fit tested in their own respirator. This drink tube fit test adapter is for all Avon gas masks. This is the adapter only, not a kit.

PC50	C50	FM50	FM53

800577

POWERED AIR SPARE PARTS



Li-lon 8 Hour Rechargeable Battery

8 hour rechargeable battery for the C420 blower and ST PAPR Must be used with Li-Ion Battery charger (70501-237). Ensure battery is fully recharged prior to each use. Alternative green colored Battery Cap Assembly (70501-244) supplied with battery must be used on blower unit when fitting battery.

C420	ST-PAPR	Avon EZAir

70501-235



Li-Ion Rechargeable Battery

Intelligent battery charge for use with Li-Ion Rechargeable Battery (70501-235). Colored LED lights the charger informs the user when the battery requires charging and when fully charged. Supplied with US electrical plug unless specified at time of order.

C420	ST-PAPR	Avon EZAir

70501-237



Battery Cap Assembly

Replacement battery cap for blower unit in green, to be used with Li-lon Rechargeable Battery (70501-235) only.

C420	ST-PAPR	Avon EZAir

70501-244



LiSO₂ Battery (One time use only) Long storage life (10 years) Lithium

Long storage life (10 years) Lithium Sulfur Dioxide battery (BA-5800) for single time use only. Provides a minimum 8 hours run time. Discharge for disposal by designated personnel only. Sold in packs of 2.

C420	ST-PAPR	Avon EZAir

70501-218



MH 4.8v Rechargeable Battery with Cap

Latest technology 4 hour rechargeable battery for the C420 blower. Must be used with the NiMH 4-8v rechargeable battery charger (80500-11). Ensure that battery is fully recharged prior to each use.

C420	ST-PAPR	Avon EZAir

80500-12



NiMH 8 Hour Rechargable Battery Charger

Intelligent battery charger for use with the NiMH 4-8v Rechargeable Battery with Cap (80500-12). Supplied with US electrical plug unless specified at time of order

C420	ST-PAPR	Avon EZAir

80500-11

POWERED AIR SPARE PARTS



Canister Port Gaskets

CBRN hardened rubber sealing gasket for Canister interface with C420 and ST-PAPR blower unit. Inspect regularly and replace immediately if damaged or excessive compression set in material is visible. Grey in color.

C420	ST-PAPR	Avon EZAir

(pack of 10) 70501-242



Breathing Tube

CBRN hardened butyl rubber hose for use with C420 PAPR blower. Available in two lengths 30" and 36". When fitting PAPR system to user, ensure that there is sufficient length in the hose to allow for head and body movement, use shorter hose if excessive hose length observed. Ensure sealing Gaskets are inspected regularly, replace with Gasket (70501-243).

C420	ST-PAPR	Avon EZAir		
			30"	70501-213
			36"	70501-214



Breathing Tube Gasket

CBRN hardened rubber sealing gasket for breathing hose interface with APR and C420 blower unit. Inspect regularly and replace immediately if damaged or excessive compression set in material is visible.

C420	ST-PAPR	Avon EZAir

(pack of 10) 70501-243



Hose Cover w/Zipper

Made from tough, rip stock nylon, the replaceable hose cover is available in two lengths - 34" and 28" for use with 36" and 30" close fit hose assemblies respectively. Integrated webbing allow for easy attachment to clothing/body armor to deliver secure fit with no snag points. Full length zipper aids easy fitting and removal for cleaning.

C420	ST-PAPR	Avon EZAir		
			28"	84200-10-5
			34"	84100-10-4



Flow Indicator

Designed to visibly show that PAPR blower unit is providing sufficient airflow to the APR. Simply pushes into blower hole where Breathing Tube normally attaches. Use as directed in Operator Manual (70501-241)

C420	ST-PAPR	Avon EZAir

70501-219



ST53 Combo Carrier

Modular carrier system to allow ST-PAPR to be attached to either a 30,45 or 60 minute SCBA cylinder for Combination Respirator Unit (CRU) operation. Made from tough, rip stock nylon.

C420	ST-PAPR	Avon EZAir

038021



Dust-Decon Canister Covers

Rubberized covers (pair supplied) that fit simply over the Canisters to provide shower proof protection, ideal in a decontamination scenario.

C420	ST-PAPR	Avon EZAir

70501-270



Blower Belt

Adjustable belt to allow Avon EZAir to be worn around users waist.

	Avon EZAir	ST-PAPR	C420	
84200-10-	60"			
84200-10-2	70"			

POWERED AIR SPARE PARTS



Avon EZAir Blower NLM (Non CBRN)

The compact blower accepts traditional and conformal 40mm STANAG threaded Canisters and uses the same Canister mount gasket as C50 for simpler maintenance. The press and

hold power button allows for easy operation and prevents accidental switching off through a delayed power down setting. Supplied with a factory setting for a low battery alarm, the unit accepts three battery pack configurations, depending on operational needs. The blower accepts traditional and close fit hose options and is simply mounted to the user through use of the carrier system. (This blower is not approved for use with CBRN challenges)

C420	ST-PAPR	Avon EZAir

81100-10



Sweep Hose

The patented design of the hose interface to the APR, delivers optimum integration with Avon APRs, guiding the hose backwards while preventing it from falling off the wearer's shoulder. The simple to operate release button allows the APR hose end to be quickly

removed and refitted from the APR, ideal for pre APR & helmet donning. The hose construction is crush resistant and made from robust flexible rubber. Hose assembly is supplied with quick release adapter (80141-32). Protective hose cover is not included

		Avon EZAir	ST-PAPR	C420	
80100-10	30"				
80100-11	36"				



Replaceable Battery Pack (CR123)

The 'hot swap' design allows the user to remove the battery quickly from the blower without loss of protection. The 4 cell configuration accepts the widely available CR-123 Li-lon battery, commonly used in most weapon flash lights. A simple to remove lid allows user level battery replacement.

C420	ST-PAPR	Avon EZAir

81100-11



Quick Release Adapter

The replacement part provides the quick release interface between the close fit hose assembly / other accessories and the APR. Adapter fits all Avon 40mm STANAG Canister mounts.

C420	ST-PAPR	Avon EZAir

80141-32



O-Ring Kit, Quick Disconnect

Replacement pre-greased sealing o-rings (Qty 2) for user with close fit hose (80100-11 & 80100-10). Essential that both o-rings are inspected regularly as part of the APR/blower maintenance program and replaced if showing signs of wear or damage.

C420	ST-PAPR	Avon EZAir

81130-10

MANUALS

Operator manuals provide wearer with a detailed overview on APR maintenance and fitting procedures.

70501-612	PC50 User Manual
70501-84	C50 User Manual
71601-30	FM50 User Manual
72601-59	FM53 User Manual
70501-241	C420 User Manual
084141	ST53 SCBA User Manual
084155	ST53 User Manual
084171	ST-PAPR User Manual
81135-10	Avon EZAir User Manual



GR13280-01

